

NOTE: If the pump is disassembled within the warranty period, the pump is no longer covered by the warranty

DISASSEMBLY

1. Tools required for dismantling the pump



2. Loosen and remove 4 screws



3. Remove mounting flange



4. Remove spring



5. Remove shaft sealing



6. Remove 2 guide pins



7. Remove O-ring



8. Turn pump upside down



9. Loosen and remove 10 screws



10. Remove cover



- 11.



12. Remove pistons and retainer plate



13. Remove retainer ball



14. Remove retainer



15. Remove spring



16. Remove cylinder barrel



17. Remove port plate



18. Remove 1 guide pin



19. Turn pump upside down and remove 2 washers



20. Loosen and remove 6 screws




21. Remove port flange



22. Remove 1 guide pin



23. Remove O-ring from port flange




24. Loosen thrust plate from cylinder barrel



25. Remove thrust plate



26. Remove O-rings from thrust plate




27. Remove backup rings from thrust plate



28. Remove 1 guide pin from end cover plate



29. Loosen and remove screw from swash plate



30. Remove swash plate




31. Remove 2 guide pins from end cover plate



32. Remove O-ring from end cover plate



- 34.



33. Remove shaft sealing from mounting flange




35. Pump disassembled




INSPECTION:

Valve and thrust plate

1. Neither valve plate nor thrust plate must show any sign of wear.



2. Hold a ruler against surface of plate and check tightness against a light source.



3. Check that both O-rings and back-up rings are not broken and do not show severe wear.


Swash plate:

1. Check that surface of swash plate is smooth and without any large scratches (depth more than 0.1 mm).



Pistons


1. Play in ball and socket joint must not exceed 0.1 mm.
2. Thickness of piston shoes must be at least 4.4 mm.



3. Hold a ruler against surfaces of piston shoes to check that the surfaces are even and smooth and without any scratches. It is acceptable that the (black) treated surfaces of the pistons are partly worn.



4. Check bushes in cylinder barrel for wear and scratches



5. Check main bearing for wear and scratches



ASSEMBLY

1. Tools required for assembly of the pump



2. Parts needed for assembly of the pump



WARNING:


Do not use silicone when assembling the pump. Do not reuse disassembled O-rings; they might be damaged. Always use new O-rings.

Important:

It is essential that the pump is serviced in conditions of absolute cleanliness. All parts must be absolute clean before mounting.

Lubrication:


- To prevent seizing-up, lubricate all threads with PTFE lubrication type.
- O-rings inside pump may be lubricated only with clean filtered water.
- O-rings for port flange, mounting flange and flushing valve must be lubricated.
- It is important to lubricate ALL parts to be assembled with clean filtered water (Especially all PEEK parts).



3. Mount 1 guide pin in housing



4. Mount O-ring in port flange



5. Mount port flange on housing. Use pin as guide



6. Mount 6 screws (M8x55)



7. Tighten screws to 30Nm



8. Turn pump upside down



9. Mount 1 guide pin inside the housing on the back side of the port plate



10. Mount port plate. Be aware of orientation/guide pin



11. Mount backup rings on the thrust plate



12. Mount O-rings on the thrust plate



13. Spray with water on cylinder barrel and thrust plate



14. Mount thrust plate on cylinder barrel



15. Press thrust plate into cylinder barrel



16. Mount cylinder barrel in housing



17. Mount spring



18. Mount retainer on top of the spring



19. Spray with water and mount retainer ball



20. Place retainer plate on top of retainer ball




21. Spray with water and mount pistons



22. Spray with water and mount O-ring on end cover




23. Mount 2 guide pins on endcover




24. Mount swash plate



25. Mount screw (M8x20)



26. Tighten screw to 30Nm



27. Mount 1 guide pin on housing



28. Spray piston shoes with water



29. Mount endcover on the housing



30. Mount 10 screws (M8x20)



31. Tighten 10 screws to 30Nm



32. Turn pump upside down and mount 2 guide pins




33. Spray with water and mount O-ring




34. Spray shaft sealing with water before mounting



35. Mount shaft sealing



36. Use tool and press shaft sealing into place



37. Mount transparent ring



41. Spray with water



38. Mount metal ring



42. Mount sealing (smallest diameter pointing down)



39. Mount spring



43. Mount mounting flange



40. Mount special tool on shaft



44. Mount 4 screws



45. Tighten screws to 30Nm




46. Finished




Spare parts list for PAHT 50-90				180B4196 - Seal set (PAHT 50-90)	180B4195 - Cylinder barrel set (PAHT 50-90)	180B4192 - Valve plate set (PAHT 50-70)	180B4193 - Valve plate set (PAHT 80-90)	180B4194 - Piston set (PAHT 50-90)	180B4252 - Swash plate set (PAHT 50)	180B4255 - Swash plate set (PAHT 63)	180B4258 - Swash plate set (PAHT 70)	180B4253 - Swash plate set (PAHT 80)	180B4256 - Swash plate set (PAHT 90)
Pos.	Qnt.	Designation	Material										
1	1	Housing	AISI 316										
2	2	Pin ø4 x 14	AISI 304	x									
5	10	Screw M8 x 16	AISI 304	x									
9	1	O-ring ø135 x 3	NBR	x									
11	1	End cover CW	AISI 316										
31	1	Swash plate	AISI 431						x	x	x	x	x
32	1	Screw M8 x 20	AISI 304						x	x	x	x	x
34	2	Pin ø4 x 14	AISI 304						x	x	x	x	x
61	1	Cylinder barrel	AISI 431		x								
62	1	Spring	1.4462					x					
64	1	Retainer ball	AISI 431					x					
65	1	Retainer plate	AISI 304					x					
66	9	Piston	AISI 431/ PEEK					x					
67	1	Key 8 x 7 x 32	AISI 316Ti	x									
70	1	Washer	Polypropylen	x									
71	1	Retainer	AISI 304 / PEEK					x					
91	1	Port plate	AISI 304 / PEEK			x	x						
92	1	Valve plate	AISI 431			x	x						
93	9	Back up ring	PTFE			x	x						
94	9	O-ring ø18,3 x 2,4	NBR			x	x						
121	1	Port flange	AISI 316										
122	1	O-ring ø135 x 3	NBR	x									
123	1	O-ring Ø65 x 5	NBR	x									
124	1	Shaft sealing	AISI 304 / NBR	x									
125	1	End cover	AISI 316										
126	1	Pin ø6 x 10	AISI 304			x	x						
127	6	Screw M8 x 70	AISI 304	x									
128	4	Screw M8 x 55	AISI 304	x									
	1	Service instruction		x									

Exploded view for
PAHT 50-90



Spare parts list for PAHT G 50-90				180B4341 - Seal set (PAHT G 50-90)	180B4339 - Cylinder barrel set (PAHT G 50-90)	180B4340 - Valve plate set (PAHT G 50-70)	180B4344 - Valve plate set (PAHT G 80-90)	180B4343 - Piston set (PAHT G 50-90)	180B4326 - Swash plate set (PAHT G 50)	180B4327 - Swash plate set (PAHT G 63)	180B4328 - Swash plate set (PAHT G 70)	180B4329 - Swash plate set (PAHT G 80)	180B4330 - Swash plate set (PAHT G 90)
Pos.	Qnt.	Designation	Material										
1	1	Housing	AISI 316										
2	2	Pin ø4 x 14	AISI 304	x									
5	10	Screw M8 x 16	AISI 304	x									
9	1	O-ring ø135 x 3	NBR	x									
11	1	End cover CW	AISI 316										
31	1	Swash plate	AISI 431						x	x	x	x	x
32	1	Screw M8 x 20	AISI 304						x	x	x	x	x
34	2	Pin ø4 x 14	AISI 304						x	x	x	x	x
61	1	Cylinder barrel	AISI 431		x								
62	1	Spring	1.4462					x					
64	1	Retainer ball	AISI 431					x					
65	1	Retainer plate	AISI 304					x					
66	9	Piston	AISI 431 / PEEK					x					
67	1	Key 8 x 7 x 32	AISI 316Ti	x									
70	1	Washer	Polypropylen	x									
71	1	Retainer	AISI 304 / PEEK					x					
91	1	Port plate	AISI 304 / PEEK			x	x						
92	1	Valve plate	AISI 431			x	x						
93	9	Back up ring	PTFE			x	x						
94	9	O-ring ø18,3 x 2,4	NBR			x	x						
121	1	Port flange	AISI 316										
122	1	O-ring ø135 x 3	NBR	x									
123	1	O-ring Ø65 x 5	NBR	x									
124	1	Shaft sealing	AISI 304 / NBR	x									
125	1	End cover	AISI 316										
126	1	Pin ø6 x 10	AISI 304			x	x						
127	6	Screw M8 x 70	AISI 304	x									
128	4	Screw M8 x 55	AISI 304	x									
	1	Service instruction		x									

Exploded view for
PAHT G 50-90



Tool sets		180Z0237 - Tool set (PAH / PAHT / PAHT G 20-32)
Qty.	Designation	
1	Shaft bush, torpedo	
1	Press tool 1	
1	Press tool 2	
Danfoss A/S High Pressure Pumps DK-6430 Nordborg Denmark Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.		