

| Number | P.N.       | Description                                |
|--------|------------|--------------------------------------------|
|        | 1 1031740  | Skipper Wheel Assembly – 6 Day             |
|        | 1 1031742  | Skipper Wheel Assembly – 7 Day             |
|        | 2 1030659  | Washer                                     |
|        | 3 3030002  | Motor Cap Screw                            |
|        | 4 3030003  | Bowed Washer                               |
|        | 5 1031756  | Tripper Arm Assembly                       |
|        | 6 1030830  | Spring                                     |
|        | 7 1030821  | Retainer                                   |
|        | 8 1031751  | Motor Cap (440-450) N.A.                   |
|        | 9 1005615  | Motor fastening Screw N.A.                 |
|        | 10 1007416 | Wire Nut                                   |
|        | 11 1030846 | Motor 115V.60 Hz (440-450)                 |
|        | 11 1000377 | Motor 230V.50 Hz (440-450)                 |
|        | 11 3003134 | Motor 24V.50 Hz (440-450)                  |
|        | 11 1030850 | Motor 24V.60 Hz (440-450)                  |
|        | 11 1031557 | Motor 200V.60 Hz (440-450) N.A.            |
|        | 11 1008205 | Motor 12V.50 Hz -440 N.A.                  |
|        | 11 1008206 | Motor 12V.60 Hz -440 N.A.                  |
|        | 12 1001568 | Motor 12V.50 Hz (440i)                     |
|        | 12 1001569 | Motor 12V.60 Hz (440i)                     |
|        | 12 1000098 | Motor 9V.50 Hz (460i – 460tc)              |
|        | 12         | Motor 9V.60 Hz (460i – 460tc)              |
|        | 13 1000814 | European Transformer 230/12V               |
|        | 13 1000813 | British Transformer                        |
|        | 13 1000811 | American transformer 120/12V               |
| *      | 1001582    | Red Start Button -440 N.A.                 |
| *      | 1031558    | Red Start Button (450-460) N.A.            |
|        | 14 1001833 | Output Connector w/Black Start Button 440i |
| *      | 1001000    | Black Start Button (460i – 460tc)          |
| *      | 1031496    | Output Connector 440 N.A.                  |
| *      | 1000094    | Timer Window 460i – 460tc                  |
| *      | 1005120    | Cable press w/cable -440                   |
|        | 15 1031554 | Black gear 119' A (INF. #8) [ 420A4 ]      |
|        | 16 1030844 | Black gear 119' B [ 420A44 ] 1,14          |
|        | 17 1030842 | White gear 59' A (INF. #13) [ 420A4 ]      |
|        | 18 1030843 | White gear 59' B [ 420A42 ] 1,14           |
| *      | 1031555    | Black gear 90' A (INF. #10)                |
| *      | 1030845    | Black gear 90' B                           |
| *      | 1004501    | Retaining ring 440 (20E) N.A.              |
|        | 19 1030841 | White gear for timer 440i                  |
| *      | 1051826    | Timer 440i 7GG 119' 12V.50 Hz ITA          |
| *      | 44IL12L56f | Timer 440i 6GG 119' 12V.50 Hz ITA          |

\* 1051827 Timer 440i 7GG 59' 12V.50 Hz ITA  
\* Timer 440i 6GG 59' 12V.50 Hz ITA  
\* 1040779 Timer 440i 7GG 119' 12V.60 Hz US.  
\* Timer 440i 6GG 119' 12V.60 Hz US.  
\* 44ILE2L67F Timer 440i 7GG 59' 12V.60 Hz US.  
\* Timer 440i 6GG 59' 12V.60 Hz US.  
\* 3031461 Timer 440i 7GG 119' 12V.50 Hz for filtration  
\* 1051828 Timer 440i 7GG 119' 12V.50 Hz E.  
\* Timer 440i 6GG 119' 12V.50 Hz E.  
\* 44ILE2L57F Timer 440i 7GG 59' 12V.50 Hz E.  
\* Timer 440i 6GG 59' 12V.50 Hz E.  
\* 4000610 Timer 460tc 118' 12V.50 Hz symbols  
\* 4000611 Timer 460tc 59' 12V.50 Hz symbols  
\* Timer 460tc 118' 12V.60 Hz US.  
\* Timer 460tc 59' 12V.60 Hz US.  
\* 1262929 Timer 450i 119' 24V.50 Hz  
\* Timer 450i 119' 24V.60 Hz US.  
\* 1030007 Timer 460i 119' 12V.50 Hz symbols  
\* 1051811 Timer 460i 59' 12V.50 Hz symbols  
\* 1030000 Timer 460i 119' 12V.60 Hz US.  
\* Timer 460i 59' 12V.60 Hz US.