

ABCOR[®] - INDUCOR[™]-G MODULE: 10-HFM-251-ICV

Industrial Multitubular Ultrafiltration Module

PRODUCT DESCRIPTION	Part Number (KPN)	0712501
	Membrane Chemistry:	PVDF
	Membrane Type:	HFM (neutral charge)
	Membrane Area:	15.4 ft ² (1.4 m ²)
	Molecular Weight Cut-Off:	100,000 Dalton (nominal)
	Construction:	Seven (7) 1" diameter tubules in a PVC shell
	Face Plate:	ABS
	Gasket:	VITON [®]


OPERATING AND DESIGN INFORMATION*	Maximum Inlet Pressure:	90 psi @ 119 °F (6.2 bar @ 48 °C)
	Maximum Operating Temperature:	122°F (50 °C) at 84 psi max
	Maximum Permeate Side Back Pressure:	3 psi (0.2 bar)
	Minimum Outlet Pressure:	5 psi (0.3 bar)
	Maximum Feed Side Pressure Drop:	6.6 psi @ 119 °F (0.4 bar @ 48 °C)
	Allowable pH - Continuous Exposure:	2.0 – 10.0 @ 119 °F (48°C)
	Allowable pH - Short Term Exposure:	1.5 – 10.5 @ 119 °F (48°C)

* Consult KMS Industrial Process Technology Group for specific applications.

FEED FLOW VS. PRESSURE DROP*	Circulation Flow		Crossflow Velocity		Pressure Drop	
	gpm	m ³ /hr	f/s	m/s	psi	bar
	133	30	7.8	2.4	2.0	0.14
	210	48	12.3	3.7	4.3	0.29
	266	60	15.5	4.7	6.0	0.41

* Data based on water at 77° F and specific gravity of 1.0.

NOMINAL DIMENSIONS



ANCILLARY PARTS

KMS recommends that these membranes be used with KMS supplied ancillary parts. Sealing is provided by o-rings and gaskets. No additional sealing compound or tape is recommended for use on threaded connections.




INDUCOR™-G Module Process Pass Kits

One Process Pass Kit contains;
Two Permeate Port Saddle Assemblies
Two 4" Coupling Assemblies

Available in two styles of Permeate Port Saddle:

1" IPS Socket Style Pass Kit KPN 0211875

1" FNPT Threaded Style Pass Kit KPN 0211885



MEMBRANE INCOMPATIBILITY

Prior to exposing the membrane to any chemical, the chemical should be reviewed by Koch Membrane Systems. Aside from the listed chemicals below, synthetic coolants, semi-synthetic coolants, kerosenes, naphtha, gasoline, floc polymers may affect membrane performance.

Chemicals that should be avoided include the following:

- Aprotic Solvent (e.g., Dimethyl Formamide, Dimethyl Acetamide, N-Methyl Pyrrolidine, etc.)
- Chlorinated Solvents (e.g., Methylene Chloride, Chloroform, Carbon Tetrachloride, etc.)
- Ketones (e.g., Acetone, Diacetone Alcohol, etc.)
- Silicones or Silicone based Defoamers (e.g., Siloxane)

The information contained in this publication is believed to be accurate and reliable, but is not to be construed as implying any warranty or guarantee of performance. We assume no responsibility, obligation or liability for results obtained or damages incurred through the application of the information contained herein. Refer to Standard Terms and Conditions of Sale for additional information.

LENNTECH

info@lenntech.com Tel. +31-152-610-900

www.lenntech.com Fax. +31-152-616-289